

Compatible Notification Appliances for use with SIEMENS Models:

CP-2ER
FireFinder-XLS
MXL/MXLV
MXL-IQ
PAD-2
PAD-3
PXL
SXL
SXL-EX
System 3
VoiceCom

Compatible Notification Appliances

Category	Product	Category	Product	Category	Product
Electro.-Mech. Horns	HN-C	Electro.-Mech. Horns/Strobes (Cont.)	U-HN	Strobes (Cont.)	S30-STD
	HN-EP		U-HN-W		S30-SGL
	HN-F		U-HN-S17		S30-SUR
	HN-S		U-HN-S17-W		S30-RET
	HNH-C		U-HN-S30		S75-STD
	HNH-EP		U-HN-S30-W		S75-SGL
	HNH-F		U-HN-S60		S75-SUR
	HNH-S		U-HN-S60-W		S75-RET
Electro.-Mech. Horns, AC Devices²	HN-C-AC		U-HN-S75		S15/75-STD
	HN-F-AC		U-HN-S75-W		S15/75-SGL
	HN-S-AC		U-HN-S110		S15/75-SUR
	HN-S15-C-AC		U-HN-S110-W		S110-STD
	HN-S15-F-AC		U-HN-S17-1		S110-SGL
	HN-S15-S-AC		U-HN-S17-1-W		S110-RET
	HN-S17-C-AC		U-HN-S110-1		S15-FS
	HN-S17-F-AC		U-HN-S110-1-W		S15-F
	HN-S17-S-AC		U-HN-C		S15-FT
	HN-S75-F-AC		U-HN-S17-C		S15-ST
	HN-S75-S-AC		U-HN-S17-1-C		S15-S
	HN-S110-F-AC		U-HN-S17-1-W-C		S17-FS
	HN-S110-S-AC		U-HN-S30-C		S17-F
			U-HN-S60-C		S17-FT
Electro.-Mech. Horns/Strobes	HN-S15-C		U-HN-S75-C		S17-ST
	HN-S15-F		U-HN-S110-C		S75-FS
	HN-S15-S		U-HN-S110-1-C		S75-F
	HN-S17-C		U-HN-S110-1-W-C		S75-S
	HN-S17-F		U-HNH-S17-1-C		S75-FT
	HN-S17-S		U-HNH-S17-1-W-C		S75-ST
	HN-S75-F		U-HNH-S110-1-C		S110-FS
	HN-S75-S		U-HNH-S110-1WC		S110-S
	HN-S110-F		U-HN-MCS		S110-ST
	HN-S110-S		U-HN-MCS-W		U-S17
	HNH-S15-C		U-HN-MCS-C		U-S17-W
	HNH-S15-F		U-HNH-MCS		U-S17-1
	HNH-S15-S		U-HNH-MCS-W		U-S17-1-W
	HNH-S17-C		U-HNH-MCS-C		U-S17-C
	HNH-S17-F	Strobes	SVMT-F		U-S17-W-C
	HNH-S17-S		SVM1T-F		U-S17-1-C
	HNH-S75-C		SVM3T-SO		U-S17-1-W-C
	HNH-S75-F		S15-STD		U-S30
	HNH-S75-S		S15-SGL		U-S30-W
	HNH-S110-F		S15-SUR		U-S30-C
	HNH-S110-S		S15-RET		U-S30-W-C
					U-S60

¹These modules must be used with a Synchronizing Control Module (DSC, DSC-W, SCM-F, SCM-FW, or ZIC-4A connected to FireFinder-XLS).

²These modules are to be used with System 3 or FireFinder-XLS.

³These modules are to be used with MXLV or VoiceCom.

⁴These modules must be used with a DSC, DSC-W, SCM-F or SCM-FW.

Compatible Notification Appliances

Category	Product	Category	Product	Category	Product
Strobes (Cont.)	U-S60-W	Strobes, AC Devices² (Cont.)	U-S30-AC-C	Bell/Strobe Plates (Cont.)	U-S60-6090V
	U-S60-C		U-S30-AC-W-C		U-S60-6090V-W
	U-S60-W-C		U-S60-AC		U-S75-6090V
	U-S75		U-S60-AC-W		U-S75-6090V-W
	U-S75-W		U-S60-AC-C		U-S110-6090V
	U-S75-C		U-S60-AC-W-C		U-S110-6090V-W
	U-S75-W-C		U-S75-AC		U-MCS-6090V
	U-S110		U-S75-AC-W		U-MCS-6090V-W
	U-S110-W		U-S75-AC-C		
	U-S110-1		U-S75-AC-W-C	Bell/Strobe Plates, AC Devices²	U-S17-6090V-AC
	U-S110-1-W		U-S110-AC		U-S17-6090VACW
	U-S110-C		U-S110-AC-W		U-S30-6090V-AC
	U-S110-W-C		U-S110-AC-C		U-S30-6090VACW
	U-S110-1-C		U-S110-AC-W-C		U-S60-6090V-AC
	U-S110-1-W-C		U-S17-1-AC		U-S60-6090VACW
	U-MCS		U-S17-1-AC-W		U-S75-6090V-AC
	U-MCS-W		U-S17-1-AC-C		U-S75-6090VACW
Strobes, AC Devices²	S15-F-AC		U-S17-1-AC-W-C		U-S110-6090V-AC
	S15-FS-AC		U-S110-1-AC		U-S110-6090VACW
	S15-S-AC		U-S110-1-AC-W	Vibrating Bells	BE-F
	S17-F-AC		U-S110-1-AC-C		BE-LC
	S17-FS-AC		U-S110-1-AC-W-C		BF-F
	S17-S-AC	Bells			BF-LC
	S75-F-AC				BS-F
	S75-FS-AC	Single Stroke Bells	MBDC-6		BS-LC
	S75-S-AC		MBDC-10		BT-F
	S110-F-AC				BT-LC
	S110-FS-AC			Vibrating Bells, AC Devices²	BE-AC
	S110-S-AC	Single Stroke Bells, AC Devices²			BF-AC
	S15-FT-AC				BS-AC
	S15-ST-AC	Bell/Strobe Plates	BS-SS-AC		BT-AC
	S17-FT-AC		BT-SS-AC	Electro- Mechanical Horn/Strobes AC Devices²	U-HN-AC
	S17-ST-AC				U-HN-AC-W
	S75-FT-AC		S15-6060H		U-HN-S17-AC
	S75-ST-AC		S15-6090V		U-HN-S17-AC-W
	S110-FT-AC		S17-6060H		U-HN-S30-AC
	S110-ST-AC		S17-6090V		U-HN-S30-AC-W
	U-S17-AC		S75-6090V		U-HN-S60-AC
	U-S17-AC-W		S110-6090V		U-HN-S60-AC-W
	U-S17-AC-C		U-S17-6090V		U-HN-S75-AC
	U-S17-AC-W-C		U-S17-6090V-W		U-HN-S75-AC-W
	U-S30-AC		U-S30-6090V		
	U-S30-AC-W		U-S30-6090V-W		

¹These modules must be used with a Synchronizing Control Module (DSC, DSC-W, SCM-F, SCM-FW, or ZIC-4A connected to FireFinder-XLS).

²These modules are to be used with System 3 or FireFinder-XLS.

³These modules are to be used with MXLV or VoiceCom.

⁴These modules must be used with a DSC, DSC-W, SCM-F or SCM-FW.

Compatible Notification Appliances

Category	Product	Category	Product	Category	Product
Electro-Mechanical Horn/Strobes AC Devices² (Cont.)	U-HN-S110-AC	Mini-Horns (Cont.)	MH-S15-UW	Steady Tone Mini-Horn/Strobes (Cont.)	U-MH-S60-W-C
	U-HN-S110-AC-W		MH-S17-U		U-MH-S75-C
	U-HN-S17-1-AC		MH-S17-UW		U-MH-S75-W-C
	U-HN-S17-1-AC-W		MH-S75-U		U-MH-S110-C
	U-HN-S110-1-AC		MH-S75-UW		U-MH-S110-W-C
	U-HN-S110-1ACW		MH-S110-U		U-MH-MCS
	U-HN-S17-1-AC-C		MH-S110-UW		U-MH-MCS-W
	U-HN-S17-1ACWC		MHT-1G	Steady/Temporal Tone Mini-Horn/Strobes	U-MHT-1G
	U-HN-S110-1ACC		MHT-1GW		U-MHT-1G-W
	U-HN-S110-1ACWC		MHT-U		U-MHT
	U-HN-S17-AC-C		MHT-UW		U-MHT-W
	U-HN-S30-AC-C		MHT-S15-U		U-MHT-S17
	U-HN-S60-AC-C		MHT-S15-UW		U-MHT-S17-W
	U-HN-S75-AC-C		MHT-S17-U		U-MHT-S30
	U-HN-S110-AC-C		MHT-S17-UW		U-MHT-S30-W
			MHT-S75-U		U-MHT-S60
			MHT-S75-UW		U-MHT-S60-W
			MHT-S110-U		U-MHT-S75
			MHT-S110-UW		U-MHT-S75-W
					U-MHT-S110
Bell/Strobe Plates Mechanical HDB Horn/Strobes	U-HNH	Tri-Tone Horn	SEA-1 ²		U-MHT-S110-W
	U-HNH-W		SEA-3		U-MHT-S17-C
	U-HNH-S17	Tri-Horn	TTH		U-MHT-S17-W-C
	U-HNH-S17-W				U-MHT-S30-C
	U-HNH-S30	Steady Tone Mini-Horn/Strobes	U-MH-1G		U-MHT-S30-W-C
	U-HNH-S30-W		U-MH-1G-W		U-MHT-S60-C
	U-HNH-S60		U-MH		U-MHT-S60-W-C
	U-HNH-S60-W		U-MH-W		U-MHT-S75-C
	U-HNH-S75		U-MH-S17		U-MHT-S75-W-C
	U-HNH-S75-W		U-MH-S17-W		U-MHT-S110-C
	U-HNH-S110		U-MH-S30		U-MHT-S110-W-C
	U-HNH-S110-W		U-MH-S30-W		U-MHT-MCS
	U-HNH-S17-1		U-MH-S60		U-MHT-MCS-W
	U-HNH-S17-1-W		U-MH-S60-W	Mini-Strobe Horns	HM-24
	U-HNH-S110-1		U-MH-S75		HM-24W
	U-HNH-S110-1-W		U-MH-S75-W		HM-15
	U-HNH-C		U-MH-S110		HM-15/75
	U-HNH-S17-C		U-MH-S17-C		HM-30
	U-HNH-S30-C		U-MH-S17-W-C		HM-75
	U-HNH-S60-C		U-MH-S30-C		HM-110
	U-HNH-S75-C		U-MH-S30-W-C		HMM-FS
	U-HNH-S110-C		U-MH-S60-C		
Mini-Horns	MH-1G				
	MH-1GW				
	MH-U				
	MH-UW				
	MH-S15-U				

¹These modules must be used with a Synchronizing Control Module (DSC, DSC-W, SCM-F, SCM-FW, or ZIC-4A connected to FireFinder-XLS).

²These modules are to be used with System 3 or FireFinder-XLS.

³These modules are to be used with MXLV or VoiceCom.

⁴These modules must be used with a DSC, DSC-W, SCM-F or SCM-FW.

Compatible Notification Appliances

Category	Product	Category	Product	Category	Product
Mini-Horns/ Strobes 8-Tone	MMT-1G MMT-1GW MMT-U MMT-UW MMT-S15-U MMT-S15-UW MMT-S17-U MMT-S17-UW MMT-S75-U MMT-S75-UW MMT-S110-U MMT-S110-UW	Horn/Horn Strobes 8 Tone	MT-F MT-S MT-C MT-S15-F MT-S15-S MT-S15-C MT-S17-F MT-S17-S MT-S17-C MT-S75-F MT-S75-S MT-S110-F MT-S110-S MTL-C MTL-F MTL-S MTL-S15-C MTL-S15-F MTL-S15-S MTL-S17-C MTL-S17-F MTL-S17-S MTL-S75-F MTL-S75-S MTL-S110-F MTL-S110-S U-MMT-1G U-MMT-1G-W U-MMT U-MMT-W U-MMT-S17 U-MMT-S17-W U-MMT-S30 U-MMT-S30-W U-MMT-S60 U-MMT-S60-W U-MMT-S75 U-MMT-S75-W U-MMT-S110 U-MMT-S110-W U-MMT-S17-C U-MMT-S17-W-C	Horn/Horn Strobes 8 Tone (Cont.)	U-MMT-S30-C U-MMT-S30-W-C U-MMT-S60-C U-MMT-S60-W-C U-MMT-S75-C U-MMT-S75-W-C U-MMT-S110-C U-MMT-S110-W-C U-MMT-MCS U-MMT-MCS-W
Electronic Horns 1 Tone	EH-C EH-F EH-S			Horns/Strobe Horns (Multitones)	MT MT4 MTS-15 MTS4-15 MTS-15/75 MTS4-15/75 MTS-30 MTS4-30 MTS-75 MTS4-75
Horn/Horn Strobes 3 Tone	MC-F MC-S MC-C MC-S15-F MC-S15-S MC-S15-C MC-S17-F MC-S17-S MC-S17-C MC-S75-F MC-S75-S MC-S110-F MC-S110-S			Chimes/Tri- Tone Horns, AC Devices ²	CH-AC SS-AC TTH-AC
Electronic Horns 1 Tone with Strobe	EH-S15-F EH-S15-S EH-S15-C EH-S17-F EH-S17-S EH-S17-C EH-S75-F EH-S75-S EH-S110-F EH-S110-S			Chimes/Strobes	EC-S15-F EC-S15-S EC-S15-C EC-S17-F EC-S17-S EC-S17-C EC-S75-F EC-S75-S EC-S110-F EC-S110-S
				Chimes	EC-C EC-F EC-S CH-F CH-LC CH-SS

¹These modules must be used with a Synchronizing Control Module (DSC, DSC-W, SCM-F, SCM-FW, or ZIC-4A connected to FireFinder-XLS).

²These modules are to be used with System 3 or FireFinder-XLS.

³These modules are to be used with MXLV or VoiceCom.

⁴These modules must be used with a DSC, DSC-W, SCM-F or SCM-FW.

Compatible Notification Appliances

Category	Product	Category	Product	Category	Product
Chimes/Strobe Chimes	CES-24	Speaker Strobes ³	I-SM-25	Speaker	S-LP70-S30-W
	CEC-24		I-SM-70	Strobes	S-LP25-S60
	CHM-D		I-SM25-W	(Cont.) ³	S-LP70-S60
	CS-15W		I-SM70-W		S-LP25-S60-W
	CS-30W		I-SM25-S17		S-LP70-S60-W
	CS-75W		I-SM70-S17		S-LP25-S75
	CS-15R		I-SM25-S17-W		S-LP70-S75
	CS-30R		I-SM70-S17-W		S-LP25-S75-W
	CS-75R		I-SM25-S30		S-LP70-S75-W
	CS-15/75R		I-SM70-S30		S-LP25-S110
			I-SM25-S30-W		S-LP70-S110
Electronic Chime/Strobes	U-EC	I-SM70-S30-W		S-LP25-S110-W	
	U-EC-W	I-SM25-S60		S-LP70-S110-W	
	U-EC-S17	I-SM70-S60		S-LP25-S17-C	
	U-EC-S17-W	I-SM25-S60-W		S-LP70-S17-C	
	U-EC-S30	I-SM70-S60-W		S-LP25-S30-C	
	U-EC-S30-W	I-SM25-S75		S-LP70-S30-C	
	U-EC-S60	I-SM70-S75		S-LP25-S60-C	
	U-EC-S60-W	I-SM25-S75-W		S-LP70-S60-C	
	U-EC-S75	I-SM70-S75-W		S-LP25-S75-C	
	U-EC-S75-W	I-SM25-S110		S-LP70-S75-C	
	U-EC-S110	I-SM70-S110		S-LP25-S110-C	
	U-EC-S110-W	I-SM25-S110-W		S-LP70-S110-C	
	U-EC-C	I-SM70-S110-W		S-LP25-MCS	
	U-EC-S17-C	I-SM25-C		S-LP70-MCS	
	U-EC-S30-C	I-SM70-C		S-LP25-MCS-W	
	U-EC-S60-C	I-SM25-S17-C		S-LP70-MCS-W	
	U-EC-S75-C	I-SM70-S17-C		S-LP25-MCS-C	
	U-EC-S110-C	I-SM25-S30-C		S-LP70-MCS-C	
	U-EC-MCS	I-SM70-S30-C			
	U-EC-MCS-W	I-SM25-S60-C	Electronic Slow Whoop/ Strobe	EW-S15-C	
	U-EC-MCS-C	I-SM70-S60-C		EW-S15-F	
	I-SM25-S75-C	EW-S15-S			
	I-SM70-S75-C	EW-S17-C			
	I-SM25-S110-C	EW-S17-F			
	I-SM70-S110-C	EW-S17-S			
Speakers ³	SL25-C	I-SM70-R-C		EW-S75-F	
	SL25-F	S-LP25-S17		EW-S75-S	
	SL25-S	S-LP70-S17		EW-S110-F	
	SL70-C	S-LP25-S17-W		EW-S110-S	
	SL70-F	S-LP70-S17-W			
	SL70-S	S-LP25-S30	Electronic Slow Whoop	EW-C	
	S-LP25	S-LP70-S30		EW-F	
	S-LP70	S-LP25-S30-W		EW-S	
	S-LP25-W				
	S-LP70-W				
	S-LP25-C				
S-LP70-C					

¹These modules must be used with a Synchronizing Control Module (DSC, DSC-W, SCM-F, SCM-FW, or ZIC-4A connected to FireFinder-XLS).

²These modules are to be used with System 3 or FireFinder-XLS.

³These modules are to be used with MXLV or VoiceCom.

⁴These modules must be used with a DSC, DSC-W, SCM-F or SCM-FW.

Compatible Notification Appliances

Category	Product	Category	Product	Category	Product
Sync. Control Modules¹	DSC (Dual)	Sync. Electro-Mech. Horn/Strobes (Cont.)¹	U-HNH-S17S-1-C	Sync. Strobes (Cont.)¹	U-S110S-C
	DSC-W (Dual)		U-HNH-S17S-1WC		U-S110S-W-C
	SCM-F (Single)		U-HNH-S110S-1-C		U-S110S-1-C
	SCM-FW (Single)		U-HNH-S110S-1WC		U-S110S-1-W-C
Sync. Electro-Mech. Horn/Strobes¹	HN-S15S-C	Sync. Strobes¹	S15S-F		U-MCS
	HN-S15S-F		S15S-FS		U-MCS-W
	HN-S15S-S		S15S-FT	Sync. Bell/Strobe Plate¹	S15S-6060H
	HN-S17S-C		S15S-S		S15S-6090V
	HN-S17S-F		S15S-ST		S17S-6060H
	HN-S17S-S		S17S-F		S17S-6090V
	HN-S75S-F		S17S-FS		S75S-6090V
	HN-S75S-S		S17S-FT		U-S17S-6090V
	HNH-S15S-C		S17S-S		U-S17S-6090V-W
	HNH-S15S-F		S17S-ST		U-S30S-6090V
	HNH-S15S-S		S75S-F		U-S30S-6090V-W
	HNH-S17S-C		S75S-FS		U-S60S-6090V
	HNH-S17S-F		S75S-FT		U-S60S-6090V-W
	HNH-S17S-S		S75S-S		U-S75S-6090V
	HNH-S75S-F		S75S-ST		U-S75S-6090V-W
	HNH-S75S-S		U-S17S		U-S110S-6090V
	U-HN-S17S		U-S17S-W		U-S110S-6090V-W
	U-HN-S17S-W		U-S30S	Sync. DC Electron. Mechanical HIBB Horn/Strobes¹	U-HNH-S17S
	U-HN-S30S		U-S30S-W		U-HNH-S17S-W
	U-HN-S30S-W		U-S60S		U-HNH-S30S
	U-HN-S60S		U-S60S-W		U-HNH-S30S-W
	U-HN-S60S-W		U-S75S		U-HNH-S60S
	U-HN-S75S		U-S75S-W		U-HNH-S60S-W
	U-HN-S75S-W		U-S110S		U-HNH-S75S
	U-HN-S110S		U-S110S-W		U-HNH-S75S-W
	U-HN-S110S-W		U-S17S-1		U-HNH-S110S
	U-HN-S17S-1		U-S17S-1-W		U-HNH-S110S-W
	U-HN-S17S-1-W		U-S110S-1		U-HNH-S17S-1
	U-HN-S110S-1		U-S110S-1-W		U-HNH-S17S-1-W
	U-HN-S110S-1-W		U-S17S-C		U-HNH-S110S-1
	U-HN-S17S-C		U-S17S-W-C		U-HNH-S110S-1-W
	U-HN-S17S-1-C		U-S17S-1-C		U-HNH-S17S-C
	U-HN-S17S-1-W-C		U-S17S-1-W-C		U-HNH-S30S-C
	U-HN-S30S-C		U-S30S-C		U-HNH-S60S-C
	U-HN-S60S-C		U-S30S-W-C		U-HNH-S75S-C
	U-HN-S75S-C		U-S60S-C		U-HNH-S110S-C
	U-HN-S110S-C		U-S60S-W-C		
	U-HN-S110S-1-C		U-S75S-C		
	U-HN-S110S-1WC		U-S75S-W-C		

¹These modules must be used with a Synchronizing Control Module (DSC, DSC-W, SCM-F, SCM-FW, or ZIC-4A connected to FireFinder-XLS).

²These modules are to be used with System 3 or FireFinder-XLS.

³These modules are to be used with MXLV or VoiceCom.

⁴These modules must be used with a DSC, DSC-W, SCM-F or SCM-FW.

Compatible Notification Appliances

Category	Product	Category	Product	Category	Product
Sync. Temporal Electronic Horn/ Strobes⁴	U-MHST-1G	Sync. Steady Tone Mini-Horn/ Strobes (Cont.)⁴	U-MH-S75S-C	Sync. Horns/ Horn Strobes 3 Tone (Cont.)⁴	MC-S17S-S
	U-MHST-1G-W		U-MH-S75S-W-C		MC-S75S-F
	U-MHST		U-MH-S110S-C		MC-S75S-S
	U-MHST-W		U-MH-S110S-W-C	Sync. Horns/ Horn Strobes 8 Tone⁴	MTL-S15S-C
	U-MHST-S17S	Sync. Steady/ Temporal Tone	U-MHT-S17S		MTL-S15S-F
	U-MHST-S17S-W		U-MHT-S17S-W		MTL-S15S-S
	U-MHST-S30S	Mini-Horn/ Strobes⁴	U-MHT-S30S		MTL-S17S-C
	U-MHST-S30S-W		U-MHT-S30S-W		MTL-S17S-F
	U-MHST-S60S		U-MHT-S60S		MTL-S17S-S
	U-MHST-S60S-W		U-MHT-S60S-W		MTL-S75S-F
	U-MHST-S75S		U-MHT-S75S		MTL-S75S-S
	U-MHST-S75S-W		U-MHT-S75S-W		U-MMT-S17S
	U-MHST-S110S-W		U-MHT-S110S		U-MMT-S17S-W
	U-MHST-S17S-C		U-MHT-S110S-W		U-MMT-S30S
	U-MHST-S17S-W-C		U-MHT-S17S-C		U-MMT-S30S-W
	U-MHST-S30S-C		U-MHT-S17S-W-C		U-MMT-S60S
	U-MHST-S30S-W-C		U-MHT-S30S-C		U-MMT-S60S-W
	U-MHST-S60S-C		U-MHT-S30S-W-C		U-MMT-S75S
	U-MHST-S60S-W-C		U-MHT-S60S-C		U-MMT-S75S-W
	U-MHST-S75S-C		U-MHT-S60S-W-C		U-MMT-S110S
	U-MHST-S75S-W-C		U-MHT-S75S-C		U-MMT-S110S-W
	U-MHST-S110S-C		U-MHT-S75S-W-C		U-MMT-S17S-C
	U-MHST-S110S-W-C		U-MHT-S110S-C		U-MMT-S17S-W-C
	U-MHST-MCS		U-MHT-S110S-W-C		U-MMT-S30S-C
	U-MHST-MCS-W				U-MMT-S30S-W-C
Sync. Steady Tone Mini-Horn/ Strobes⁴	U-MH-S17S	Sync. Mini- Horns⁴	MHST-1G	Sync. Mini- Horns/Strobes 8-Tone⁴	U-MMT-S60S-C
	U-MH-S17S-W		MHST-1GW		U-MMT-S60S-W-C
	U-MH-S30S		MHST-U		U-MMT-S75S-C
	U-MH-S30S-W		MHST-UW		U-MMT-S75S-W-C
	U-MH-S60S		MHST-S15S-U		U-MMT-S110S-C
	U-MH-S60S-W		MHST-S15S-UW		U-MMT-S110S-W-C
	U-MH-S75S		MHST-S17S-U		
	U-MH-S75S-W		MHST-S17S-UW		MMT-S15S-U
	U-MH-S110S		MHST-S75S-U		MMT-S15S-UW
	U-MH-S110S-W		MHST-S75S-UW		MMT-S17S-U
	U-MH-S17S-C	Sync. Horns/ Horn Strobes 3 Tone⁴			MMT-S17S-UW
	U-MH-S17S-W-C		MC-S15S-C		MMT-S75S-U
	U-MH-S30S-C		MC-S15S-F		MMT-S75S-UW
	U-MH-S30S-W-C		MC-S15S-S		
	U-MH-S60S-C		MC-S17S-C		
	U-MH-S60S-W-C		MC-S17S-F		

¹These modules must be used with a Synchronizing Control Module (DSC, DSC-W, SCM-F, SCM-FW, or ZIC-4A connected to FireFinder-XLS).

²These modules are to be used with System 3 or FireFinder-XLS.

³These modules are to be used with MXLV or VoiceCom.

⁴These modules must be used with a DSC, DSC-W, SCM-F or SCM-FW.

Compatible Notification Appliances

Category	Product	Category	Product	Category	Product
Sync. Speaker Strobes^{3, 4}	I-SM25-S17S	Sync. Speaker Strobes (Cont.)^{3, 4}	S-LP70-S75S	Sync. Steady Tone Mini-Horn/ Strobes⁴	U-MH-MCS
	I-SM70-S17S		S-LP25-S75S-W		U-MH-MCS-W
	I-SM25-S17S-W		S-LP70-S75S-W		
	I-SM70-S17S-W		S-LP25-S110S		
	I-SM25-S30S		S-LP70-S110S	Sync. Steady/ Temporal Tone Mini-Horn/Strobes⁴	U-MHT-MCS
	I-SM70-S30S		S-LP25-S110S-W		U-MHT-MCS-W
	I-SM25-S30S-W		S-LP70-S110S-W		
	I-SM70-S30S-W		S-LP25-S17S-C		
	I-SM25-S60S		S-LP70-S17S-C	Sync. Horn/Horn Strobes 8 Tone⁴	U-MMT-MCS
	I-SM70-S60S		S-LP25-S30S-C		U-MMT-MCS-W
	I-SM25-S60S-W		S-LP70-S30S-C		
	I-SM70-S60S-W		S-LP25-S60S-C		
	I-SM25-S75S		S-LP70-S60S-C		
	I-SM70-S75S		S-LP25-S75S-C		
	I-SM25-S75S-W		S-LP70-S75S-C		
	I-SM70-S75S-W		S-LP25-S110S-C		
	I-SM25-S110S		S-LP70-S110S-C		
	I-SM70-S110S		S-LP25-MCS		
	I-SM25-S110S-W		S-LP70-MCS		
	I-SM70-S110S-W		S-LP25-MCS-W		
	I-SM25-S17S-C		S-LP70-MCS-W		
	I-SM70-S17S-C		S-LP25-MCS-C		
	I-SM25-S30S-C		S-LP70-MCS-C		
	I-SM70-S30S-C	Sync. Electronic Chime/Strobes⁴	U-EC-S17S		
	I-SM25-S60S-C		U-EC-S17S-W		
	I-SM70-S60S-C		U-EC-S30S		
	I-SM25-S75S-C		U-EC-S30S-W		
	I-SM70-S75S-C		U-EC-S60S		
	I-SM25-S110S-C		U-EC-S60S-W		
	I-SM70-S110S-C		U-EC-S75S		
	I-SM70-S75S-R-C		U-EC-S75S-W		
	S-LP25-S17S		U-EC-S110S		
	S-LP70-S17S		U-EC-S110S-W		
	S-LP25-S17S-W		U-EC-S17S-C		
	S-LP70-S17S-W		U-EC-S30S-C		
	S-LP25-S30S		U-EC-S60S-C		
	S-LP70-S30S		U-EC-S75S-C		
	S-LP25-S30S-W		U-EC-S110S-C		
	S-LP70-S30S-W		U-EC-MCS		
	S-LP25-S60S		U-EC-MCS-W		
	S-LP70-S60S		U-EC-MCS-C		
	S-LP25-S60S-W				
	S-LP70-S60S-W				
	S-LP25-S75S				

¹These modules must be used with a Synchronizing Control Module (DSC, DSC-W, SCM-F, SCM-FW, or ZIC-4A connected to FireFinder-XLS).

²These modules are to be used with System 3 or FireFinder-XLS.

³These modules are to be used with MXLV or VoiceCom.

⁴These modules must be used with a DSC, DSC-W, SCM-F or SCM-FW.

