



### Description

### Part Number

A — Batteries	See battery list below.
B — Door assembly	698-373
C — PC board options	See list below.
1 — Transformer	478-271 (120VAC)
	478-273 (220VAC)
2 — 4001 PC board	562-703
3 — Overlay	635-540
4 — Battery harness	733-462
5 — PC option harness	733-464
Style D (formerly Class A) harness	733-530
Style D (formerly Class A) harness (with other options)	733-531
6 — Snap-in standoff	202-039

### Battery List

6.2Ah —	112-112
10Ah —	112-113
18Ah —	112-046

### PC Board Options

Zone disconnect board —	562-664
Transient suppressor board —	562-657
Transient supp./zone disc. —	562-666
Relay board —	562-698
Style D (formerly Class A) board —	562-900

### Fuses

AC input 10A (F1) —	208-051
Aux. pwr. 0.75A (F2) —	208-126
Sig. ckt. 3A (F3) —	208-003
Bat. input 6A (F4) —	208-057

### Meter Option

DC voltmeter —	278-034
DC ammeter —	278-035
Harness —	733-489

### Door Assembly

Door —	698-313
Lock —	266-005
Bezel —	635-538

