



IDNet and MAPNET II Addressable Devices

Device Communications Compatibility Chart

Devices Compatible with 4008, 4010, 4010ES, 4100U, & 4100ES IDNet Communications, & MAPNET II Communications				
Model	Description	Model	Description	Listings
4090-9101	Class B IDC ZAM	4098-9791	Sensor Base, rem. LED/ relay & supv. relay	UL, ULC, FM, CSFM, MEA
4090-9106	Class A IDC ZAM	4098-9792	Standard Sensor Base	
4098-9750	In-Duct Sensor Housing without relay	4098-9794	Sounder Base	
4098-9751	In-Duct Sensor Housing with relay	4099-9001	Addressable Station, Standard	
4098-9755	Duct Sensor Housing without relay	4099-9002	Addressable Station, Breakglass	
4098-9756	Duct Sensor Housing with relay	4099-9003	Addressable Station, Push	
4098-9789	Sensor Base with connections for remote LED or unsupervised relay			
4098-XAD-100, -110, -200, -210	Air aspiration sensor housings; -100, & -110 are single inlet; -200, & -210 are dual inlet	4099-9020	NO-GRIP Single Action Addressable Station	UL, ULC, CSFM
Devices with Special Considerations				
Model	Description	Compatibility		Listings
4090-9001 4090-9051	Supervised IAMs; 4090-9051 is encapsulated and w/o LED	4008, 4010, 4010ES, 4100U, & 4100ES IDNet provide "T" sense MAPNET II provides Class B monitoring of N.O. contacts		UL, ULC, FM, CSFM, MEA (see exceptions in descriptions)
4099-9401	TrueAlert Addressable Controller	4010 IDNet (4100 and 4010ES, 4100U, & 4100ES control using RU)		
4098-9795 4098-9796	Two Address Sounder Base Two Address Standard Base	for sensor 4098-9754	4008, 4010, 4100ES, 4010ES, and 4100U IDNet, and MAPNET II; two consecutive addresses; does not provide TrueSense operation; see below for dual address 4010ES/4100U/4100ES applications of 4098-9754	
4098-9754	Photo/Heat Multi-Sensor for above bases			
4098-9754*	Photo/Heat Multi-Sensor, <u>one</u> address for photo, heat, and TrueSense operation (4100ES, 4010ES, & 4100U only)		For 4100ES, 4010ES, & 4100U IDNet only; requires only one address, use with sensor bases: 4098-9789, 4098-9791, 4098-9792, 4098-9794, 4098-9793, 4098-9797 & 4098-9798	
4099-9012	Addressable Releasing Station, Push	Use with IDNet or MAPNET II Releasing panels only		
4090-9116**	IDNet Communications Isolator	4010ES, 4100U, 4100ES and 4008 IDNet		
4090-9007†	IDNet Signal IAM	4010ES, 4100U, 4100ES IDNet (4100U requires software revision 11.11.01 or higher) or with 4008 IDNet; requires one address but consumes two unit loads†		
4190-9050† 4190-9051†	4-20 mA AMZ, revision 2.01 firmware	4010ES, 4100U, 4100ES IDNet, or 4100U & 4100ES MAPNET II Operation (MAPNET II requires one unit load, IDNet requires two unit loads†)		
VLC-600	TrueAlarm LaserCOMPACT	4010ES, 4100U, 4100ES IDNet or MAPNET II Operation		
Devices Compatible with 4010/4010ES/4100U/4100ES IDNet Communications Only (except as noted)				
Model	Description	Model	Description	Listings
4009-9201 4009-9301	4009 IDNet NAC Extender (4009 A); 4100U requires rev. 11 software or higher	4090-9002 4098-9793**	Relay IAM (also for use with 4008) Isolator Base	UL, ULC, FM, CSFM, MEA (see exceptions in descriptions)
4090-9105 4090-9107	Class B IDNet Fiber Optic Transmitter (not MEA approved) Class A	4090-9005††	Suppression Release Peripheral (SRP) without enclosure (uses 2975-9227) [ULC is not applicable]	
4009-9809 4907-9001	IDNet Repeater (not MEA approved) LED Message Board (UL & C-UL)	4090-9006††	SRP with Enclosure	
Devices Compatible w2ith 4010ES/4100U/4100ES IDNet Communications Only				
Model	Description	Model	Description	Listings
4090-9117 4090-9118* 4090-9119*	Addressable Power Isolator Relay IAM with T-Sense Input Relay IAM with unsupervised input	4090-9120* 4090-9121 4100-1274	6-Pt. Module, 4 T-Sense inputs, 2 relays Security Monitor IAM, two unit loads Microphone Multiplex Module (internal IAM)	UL, ULC, FM, CSFM, MEA
4098-9797	CO Sensor Standard Base	4098-9798	CO Sensor Sounder Base	
			UL	
Devices Compatible with MAPNET II Communications Only (refer to pages 2 and 6 for legacy products)				
Model	Description	Model	Description	Listings
2190-9153 & -9154 2190-9155 & -9156 2190-9157 & -9158 2190-9159 & -9160	Monitor ZAM, Style D, IDC Monitor ZAM, Style B, IDC 4-Wire Detector ZAM, IDC Signal ZAM, Style Z NAC	2190-9161 & -9162 2190-9163 & -9164 2190-9173 2190-9169 & -9170	Signal ZAM, Style Y NAC Control Relay ZAM, DPDT Contacts 2-Point I/O Module Line powered isolators (non-addr.)	UL, ULC, FM, CSFM, MEA
Devices Compatible with 4010 IDNet Communications or 4100U/4100ES with 4100-3106 IDNet Expansion Module				
Model	Description	Listings		
4098-9757	QuickConnect2 Sensor (uses 4098-9788 multi-purpose base)	UL, ULC, FM, CSFM, MEA		

* Requires 4010ES/4100ES (or 4100U with Revision 11.0 software or higher). ** For 4100ES & 4100U, IDNet Isolators are not compatible with the 4100-3103 Quad Panel Mount Isolator; if Quad isolator is required use 4100-3107 IDNet+ Module. [†] For IDNet communications, 1 address is assigned but the available SLC address count is reduced by 2 due to supervisory current requirements. [††] Requires 4010 Revision 3.01 software or higher; or 4100U Revision 11.05 software or higher, or 4010ES/4100ES. [LISTINGS NOTE: Listings shown are for reference; refer to individual product data sheets for detailed information.]

Device Communications Compatibility with Devices in Numerical Order (without listings)
 (This includes legacy devices not listed on page 1; refer to page 1 and product data sheets for additional information)

Model	Description	4100ES, 4010ES, & 4100U IDNet	4010 IDNet	4008 IDNet	MAPNET II
2099-9135	Addressable Station, double action push, no Simplex logo	—	—	—	✓
2099-9761	Addressable Station, double action push	—	—	—	✓
2099-9795	Addressable Station, single action	—	—	—	✓
2099-9796	Addressable Station, double action breakglass	—	—	—	✓
2099-9797	Addressable Station, single action, LOCAL	—	—	—	✓
2190-9153	Monitor ZAM, Class A, IDC; surface mount	—	—	—	✓
2190-9154	Monitor ZAM, Class A, IDC; flush mount	—	—	—	✓
2190-9155	Monitor ZAM, Class B, IDC; surface mount	—	—	—	✓
2190-9156	Monitor ZAM, Class B, IDC; flush mount	—	—	—	✓
2190-9157	4-Wire Detector ZAM, Class B IDC; surface mount	—	—	—	✓
2190-9158	4-Wire Detector ZAM, Class B IDC; flush mount	—	—	—	✓
2190-9159	Signal ZAM, Class A NAC; surface mount	—	—	—	✓
2190-9160	Signal ZAM, Class A NAC; flush mount	—	—	—	✓
2190-9161	Signal ZAM, Class B NAC; surface mount	—	—	—	✓
2190-9162	Signal ZAM, Class B NAC; flush mount	—	—	—	✓
2190-9163	Control Relay ZAM, DPDT Contacts; surface mount	—	—	—	✓
2190-9164	Control Relay ZAM, DPDT Contacts; flush mount	—	—	—	✓
2190-9169	Line Powered Isolator, non-addressable; surface mount	—	—	—	✓
2190-9170	Line Powered Isolator, non-addressable; flush mount	—	—	—	✓
2190-9172	Individual Addressable Module (IAM), includes 2190-9172A (larger) package	—	—	—	✓
2190-9173	2-Point I/O Module	—	—	—	✓
4009-9201	4009 IDNet NAC Extender (4009A); 120 VAC input	✓ (4100U requires Rev. 11 or higher)	✓	—	—
4009-9301	4009 IDNet NAC Extender (4009A); 240 VAC input	—	✓	—	—
4009-9401	TrueAlert Addressable Controller (4009T)	(use RUI)	✓	—	—
4009-9809	IDNet Repeater (mounts in 4009A or 4009T only)	✓	✓	—	—
4090-9001	Supervised IAM with LED	w/T-sense	w/T-sense	w/T-sense	no T-sense
4090-9002	Relay IAM	✓	✓	✓	—
4090-9005	Suppression Release Peripheral (SRP) no enclosure	✓ (4100U requires Rev. 11.05 or higher)	w/Rev. 3.01	—	—
4090-9006	SRP with Enclosure	—	—	—	—
4090-9007	IDNet Signal IAM; one address	✓ 2 unit loads (4100U requires Rev. 11.11.01 or higher)	—	2 unit loads	—
4090-9051	Supervised IAMs; encapsulated w/o LED	w/T-sense	w/T-sense	w/T-sense	no T-sense
4090-9101	Class B IDC ZAM	✓	✓	✓	✓
4090-9105	Class B IDNet Fiber Optic Transmitter	✓	✓	—	—
4090-9106	Class A IDC ZAM	✓	✓	✓	✓
4090-9107	Class A IDNet Fiber Optic Transmitter	✓	✓	—	—
4090-9116	IDNet Communications Isolator; see note next page *	✓	—	✓	—
4090-9117	Addressable Power Isolator	✓	—	—	—
4090-9118	Relay IAM with T-Sense Input	✓	—	—	—
4090-9119	Relay IAM with unsupervised input	✓ (4100U Rev. 11 or higher)	—	—	—
4090-9120	6-Pt. Module, 4 T-Sense inputs, 2 relays	—	—	—	—
4090-9121	Security Monitor IAM, 2 unit loads	✓	—	—	—
4098-9702	Duct Sensor for 4098-9701 Sensor Head 4-wire	—	—	—	✓
4098-9703	Duct Sensor for -9701 Sensor Head 2-wire (2120 CDT)	—	—	—	✓
4098-9704	In-Duct Sensor for 4098-9701 Sensor Head 4-wire	—	—	—	✓
4098-9705	In-Duct Sensor for -9701 Head 2-wire (2120 CDT)	—	—	—	✓
4098-9706	Duct Sensor for 4098-9701 Head 4-wire w/ 4" base	—	—	—	✓
4098-9707	Duct Sensor for -9701 Head 2-wire w/ 4" base (2120 CDT)	—	—	—	✓
4098-9708	In-Duct Sensor for 4098-9701 Head 4-wire w/ 4" base	—	—	—	✓
4098-9709	In-Duct Sensor for -9701 Head 2-wire w/ 4" base (2120 CDT)	—	—	—	✓
4098-9750	In-Duct Sensor Housing without relay	✓	✓	✓	✓
4098-9751	In-Duct Sensor Housing with relay	✓	✓	✓	✓
4098-9752	Legacy Duct Housing for 4098-9714 without relay (2120 CDT)	✓	✓	✓	✓
4098-9753	Legacy Duct Housing for 4098-9714 with relay	✓	✓	✓	✓

continued next page

Device Communications Compatibility with Devices in Numerical Order (without listings); *Continued*
 (This includes legacy MAPNET II devices not listed on page 1; refer to page 1 and product data sheets for additional information)

Model	Description	4100ES, 4010ES, & 4100U IDNet	4010 IDNet	4008 IDNet	MAPNET II
4098-9754	Photo/Heat TrueSense Multi-Sensor, 1 address, std. bases	✓ (4100U requires Rev. 11 or higher)	—	—	—
4098-9754	Photo/Heat Multi-Sensor used with dual address bases	✓	✓	✓	✓
4098-9755	Compact Duct Sensor Housing w/o relay for -9714 (2120 CDT)	✓	✓	✓	✓
4098-9756	Compact Duct Sensor Housing w/ relay for 4098-9714	✓	✓	✓	✓
4098-XAD-100, -110, -200, -210	Air aspiration sensor housings; -100, & -110 are single inlet; -200, & -210 are dual inlet	✓	✓	✓	✓
4098-9757	QuickConnect2 Sensor (uses 4098-9788 base)	✓ 4100ES/4100U requires 4100-3106	✓	—	—
4098-9781	Sensor Base 6-3/8"	—	—	—	✓
4098-9782	Sensor Base 6-3/8" w/ sounder	—	—	—	✓
4098-9783	Sensor Base 6-3/8" w/ remote relay driver	—	—	—	✓
4098-9784	Standard Sensor Base 4"	✓	✓	✓	✓
4098-9785	Sensor Base 4" w/ conn. for remote alarm ind. or relay	✓	✓	✓	✓
4098-9786	Sounder Base 6-3/8" w/ conn. for remote alarm ind. or relay	✓	✓	✓	✓
4098-9787	Sensor Base 4" w/ supv. remote relay & remote ind. or relay	✓	✓	✓	✓
4098-9789	Sensor Base; remote LED or unsupervised relay	✓	✓	✓	✓
4098-9791	Sensor Base; remote LED or relay; and supv. remote relay	✓	✓	✓	✓
4098-9792	Standard Sensor Base	✓	✓	✓	✓
4098-9793	Isolator Base; see 4100U/4100ES note below*	✓	✓	✓	—
4098-9794	Sounder Base	✓	✓	✓	✓
4098-9795	Two Address Sounder Base for 4098-9754	✓	✓	✓	✓
4098-9796	Two Address Standard Base for 4098-9754	✓	✓	✓	✓
4098-9797	CO Sensor Standard Base	✓	—	—	—
4098-9798	CO Sensor Sounder Base	✓	—	—	—
4099-9001	Addressable Station, Standard	✓	✓	✓	✓
4099-9002	Addressable Station, Breakglass	✓	✓	✓	✓
4099-9003	Addressable Station, Push	✓	✓	✓	✓
4099-9012	Addressable Releasing Station, Push (for releasing panels)	✓	✓	—	✓
4099-9020	NO-GRIP Single Action Addressable Station	✓	✓	✓	✓
4100-1274	Microphone Multiplex Module (internal IAM)	✓	—	—	—
4190-9050	4-20 mA AMZ, revision 2.01 firmware; surface mount	2 unit loads	—	—	1 unit load
4190-9051	4-20 mA AMZ, revision 2.01 firmware; flush mount		—	—	
4907-9001	LED Message Board	✓	✓	—	—
VLC-600	TrueAlarm LaserCOMPACT; emulates 4-20 mA AMZ	✓	—	—	✓

*NOTE: IDNet Isolators are not compatible with the 4100-3103 Quad Panel Mount Isolator; if required, use 4100-3107 IDNet+ Module.

4010ES/4100U/4100ES Multi-Point Device Point Allocations

NOTE: Points and/or sub-points required to be mapped over the Network are designated as "Public" in the 4010ES, 4100U, 4100ES programmer.

4009 IDNet NAC Extender (4009A)

Model	Description	Point Type	4010ES/4100U/4100ES, I/O Point Usage ¹	Public Points Usage ²
4009-9201	4009 IDNet NAC Extender, 120 VAC input	4009A4	4: 1 per NAC	up to 5; 1 per NAC, 1 for trouble
4009-9301	4009 IDNet NAC Extender, 240 VAC input			
4009-9807	Additional 4 circuit NAC, added to 4009-9201 or 4009-9301	4009A8	8: 1 per NAC	up to 9; 1 per NAC, 1 for trouble

Addressable I/O Devices

Model	Description	Point Type	4010ES/4100U/4100ES, I/O Point Usage ¹	Public Points Usage ²
4090-9118	Relay IAM with T-Sense Input	TRIAM	2; 1 for relay, 1 for input	up to 3; 1 for relay, 1 for input, 1 for trouble
4090-9119	Relay IAM with feedback (unsupervised input)	FRIAM	1; 1 point per Relay IAM	up to 3; 1 for relay, 1 for input, 1 for trouble

1, 2, See page 5 for footnotes.

continued next page

4010ES/4100U/4100ES Multi-Point Device Point Allocations (Continued)

Addressable I/O Devices (Continued)

Model	Description	Point Type	4010ES/4100U/4100ES I/O Point Usage ¹	Public Points Usage ²
4090-9120	6-Pt. Module, 4 T-Sense inputs, 2 relays	MLPTIO	6; 1 per relay, 1 per input	up to 7; 1 per relay, 1 per input, 1 for trouble

TrueAlarm Sensor Bases with 4098-9754, Photo/Heat, TrueSense Multi-Sensor

Model	Description	Point Type	Panel I/O Point Usage ¹		Public Points Usage ²
			4100ES & 4010ES	4100U	
4098-9792	Standard Sensor Base, no outputs	COMBO	1	2;	up to 4; 1 for smoke, 1 for heat, 1 for correlation, 1 for trouble
4098-9789	Sensor Base with remote LED or unsupervised relay; on with alarm			1 for smoke, 1 for heat	
4098-9791	Sensor Base; supports remote LED or relay; and supervised remote relay	RCOMBO	1	2; 1 for smoke, 1 for heat	up to 5; 1 for smoke, 1 for heat, 1 for correlation, 1 for trouble 1 for relay
4098-9793	Isolator Base	ICOMBO	1	2; 1 for smoke, 1 for heat	up to 5; 1 for smoke, 1 for heat, 1 for correlation, 1 for trouble, 1 for isolator
4098-9794	Sounder Base	SCOMBO	1	2; 1 for smoke, 1 for heat	up to 5; 1 for smoke, 1 for heat, 1 for correlation, 1 for trouble, 1 for sounder

TrueAlarm CO Sensor Standard Base 4098-9797, with Compatible Sensors

Sensor Model	Description	Point Type	Panel I/O Point Usage ¹		Public Points Usage ²
			4100ES & 4010ES	4100U	
4098-9714	Photoelectric Smoke Sensor	MCOP	1	2; 1 for photo, 1 for CO	up to 5; 1 for trouble, 1 for photo (MPHOTO), 1 for CO gas (MCOGAS), 1 for CO fire (MACOFIRE), 1 to select multi-point correlation: false alarm reduction (MACOFALSE), or faster detection (MACOFAST), or correlation off (MAOFF)
4098-9754	Multi-Sensor, Photoelectric and Heat Sensing	MCOPH	1	3; 1 for photo, 1 for heat, 1 for CO	up to 6; 1 for trouble reporting, 1 for photo (MPHOTO), 1 for heat (MHEAT) 1 for CO gas (MCOGAS), 1 for CO fire (MACOFIRE), 1 to select multi-point correlation: false alarm reduction (MACOFALSE), or faster detection (MACOFAST), or correlation off (MAOFF)
4098-9733	Heat Sensor	MCOH	1	2; 1 for heat, 1 for CO	up to 4; 1 for trouble reporting, 1 for heat (MHEAT), 1 for CO gas (MCOGAS), 1 for CO fire (MACOFIRE),
4098-9717	Ionization Smoke Sensor	MCOI	1	2; 1 for ion, 1 for CO	up to 4; 1 for trouble reporting, 1 for ion (MION), 1 for CO gas (MCOGAS), 1 for CO fire (MACOFIRE)

1, 2, See page 5 for footnotes.

continued next page

4010ES/4100U/4100ES Multi-Point Device Point Allocations; Continued

TrueAlarm CO Sensor Sounder Base 4098-9798, with Compatible Sensors; Continued

Sensor Model	Description	Point Type	Panel I/O Point Usage ¹		I/O Point Usage ²
			4100ES & 4010ES	4100U	
4098-9714	Photoelectric Smoke Sensor	MCOPS	1	2; 1 for photo, 1 for CO	up to 6; 1 for trouble reporting, 1 for sounder (MSOUND), 1 for photo (MPHOTO), 1 for CO gas (MCOGAS), 1 for CO fire (MACOFIRE), 1 to select multi-point correlation: false alarm reduction (MACOFALSE), or faster detection (MACOFAST), or correlation off (MAOFF)
4098-9754	Multi-Sensor, Photoelectric and Heat Sensing	MCOPHS	1	3; 1 for photo, 1 for heat, 1 for CO	up to 7; 1 for trouble reporting, 1 for sounder (MSOUND), 1 for photo (MPHOTO), 1 for heat (MHEAT), 1 for CO gas (MCOGAS), 1 for CO fire (MACOFIRE), 1 to select multi-point correlation: false alarm reduction (MACOFALSE), or faster detection (MACOFAST), or correlation off (MAOFF)
4098-9733	Heat Sensor	MCOHS	1	2; 1 for heat, 1 for CO	up to 5; 1 for trouble reporting, 1 for sounder (MSOUND), 1 for heat (MHEAT), 1 for CO gas (MCOGAS), 1 for CO fire (MACOFIRE),
4098-9717	Ionization Smoke Sensor	MCOIS	1	2; 1 for ion, 1 for CO	up to 5; 1 for trouble reporting, 1 for sounder (MSOUND), 1 for ion (MION), 1 for CO gas (MCOGAS), 1 for CO fire (MACOFIRE)

Footnotes:

1. 4100ES I/O Point Usage = 2500 max; 4100U I/O Point Usage = 2000 max.; 4010ES I/O Point Usage = 1000 max. Note that I/O point and device capacity may be different. Consult your Simplex product supplier for application assistance.
2. 4100U/4100ES Public Points Usage = 2500 max. per 4100U/4100ES to other Nodes. 4010ES Public Points Usage; all 4010ES points may be made public to other nodes.

MAPNET II Device Panel Compatibility (✓ = compatible)

Model	Description	with 4100-3102 MAPNET II module	4100/4100+ /4120	4020	UT*	2120 CDT**					
2099-9135	Addressable Station, double action push, no Simplex logo	compatible	compatible			compatible					
2099-9761	Addressable Station, double action push										
2099-9795	Addressable Station, single action										
2099-9796	Addressable Station, double action breakglass										
2099-9797	Addressable Station, single action, LOCAL										
2190-9153	Monitor ZAM, Class A, IDC; surface mount										
2190-9154	Monitor ZAM, Class A, IDC; flush mount										
2190-9155	Monitor ZAM, Class B, IDC; surface mount										
2190-9156	Monitor ZAM, Class B, IDC; flush mount										
2190-9157	4-Wire Detector ZAM, Class B IDC; surface mount										
2190-9158	4-Wire Detector ZAM, Class B IDC; flush mount										
2190-9159	Signal ZAM, Class A NAC; surface mount										
2190-9160	Signal ZAM, Class A NAC; flush mount										
2190-9161	Signal ZAM, Class B NAC; surface mount										
2190-9162	Signal ZAM, Class B NAC; flush mount										
2190-9163	Control Relay ZAM, DPDT Contacts; surface mount										
2190-9164	Control Relay ZAM, DPDT Contacts; flush mount										
2190-9172	IAM, includes 2190-9172A										
2190-9173	2-Point I/O Module										
4090-9008	Dual Relay IAM										
4090-9001	Supervised IAM with LED, without T-sense	compatible				yes, but without latch/track selection					
4090-9051	Supervised IAMs; encapsulated w/o LED, without T-sense										
4090-9101	Class B IDC ZAM	compatible	compatible			compatible					
4090-9106	Class A IDC ZAM										
4098-9702	Duct Sensor for 4098-9701 Sensor Head 4-wire										
4098-9703	Duct Sensor for 4098-9701 Sensor Head 2-wire										
4098-9704	In-Duct Sensor for 4098-9701 Sensor Head 4-wire										
4098-9705	In-Duct Sensor for -9701 Head 2-wire										
4098-9706	Duct Sensor for 4098-9701 Head 4-wire w/ 4" base										
4098-9707	Duct Sensor for 4098-9701 Head 2-wire w/ 4" base										
4098-9708	In-Duct Sensor for 4098-9701 Head 4-wire w/ 4" base										
4098-9709	In-Duct Sensor for -9701 Head 2-wire w/ 4" base										
4098-9750	In-Duct Sensor Housing without relay						compatible				✓
4098-9751	In-Duct Sensor Housing with relay						compatible				—
4098-9754	Photo/Heat Multi-Sensor used with dual address bases						compatible				—
4098-9755	Duct Sensor Housing without relay						compatible				✓
4098-9756	Duct Sensor Housing with relay						compatible				—
4098-9781	Sensor Base 6-3/8"						compatible	compatible			compatible
4098-9782	Sensor Base 6-3/8" w/ sounder										
4098-9783	Sensor Base 6-3/8" w/ remote relay driver										
4098-9784	Standard Sensor Base 4"										
4098-9785	Sensor Base 4" w/ conn. for remote alarm ind. or relay										
4098-9786	Sounder Base 6-3/8" w/ conn. for remote alarm ind. or relay										
4098-9787	Sensor Base 4" w/ supv. remote relay & remote ind. or relay										
4098-9789	Sensor Base; remote LED or unsupervised relay	compatible				✓					
4098-9791	Sensor Base; remote LED or relay; and supv. remote relay	compatible				—					
4098-9792	Standard Sensor Base	compatible				✓					
4098-9794	Sounder Base	compatible				—					
4098-9795	Two Address Sounder Base for 4098-9754	compatible				—					
4098-9796	Two Address Standard Base for 4098-9754	compatible				—					
4099-9001	Addressable Station, Standard	compatible				compatible					
4099-9002	Addressable Station, Breakglass										
4099-9003	Addressable Station, Push										
Model	Description	With 4100-3102 MAPNET II module	4100/4100+ /4120	4020	UT*	2120 CDT**					
4190-9050	4-20 mA AMZ, revision 2.01 firmware; surf. mount, 1 unit load	✓	revision 8 or higher	—	—	—					
4190-9051	4-20 mA AMZ, revision 2.01 firmware; flush mount, 1 unit load	✓		—	—	—					
VLC-600	TrueAlarm LaserCOMPACT; emulates 4-20 mA AMZ	✓	8.01 or higher	—	—	—					

* UT = Universal Transponder, see data sheet S4100-0007.

** 2120 CDT = Communicating Device Transponder with MAPNET II and TrueAlarm software.

MAPNET II Communications*

What does it mean?

MAPNET is an acronym for **M**ulti-**A**pplication **P**eripheral **N**ETwork. MAPNET II was introduced as an improved version of MAPNET (I) in 1991. The improvements included electrical design changes that impacted both the transmit and receive circuits and provided better electrical transient immunity and overall improved performance.

Where is it used?

Availability includes system models 4020/4100/4120 and 4100U/4100ES, and with 2120 Systems using the CDT (Communicating Device Transponder). All MAPNET II transceiver control modules communicate only with MAPNET II compatible addressable devices. (However, some addressable devices can automatically adapt to communicate with **either** MAPNET II or IDNet communication protocols.)

What does it do?

MAPNET II is an addressable communications protocol that provides power and half-duplex communications over a single pair of wires for up to **127 addressable devices**. (Half-duplex communications are bi-directional, but occur in one direction at a time.) Information can include status (normal, trouble, alarm, abnormal, etc.) and commands such as turn on or off a relay, reset a ZAM, or activate a sounder base. Additionally, TrueAlarm analog sensor information is communicated via MAPNET II communications (or IDNet communications).

How does it work?

The control panel sends out polling commands for status monitoring or individual device commands. This occurs by imposing voltage variations on a steady DC level. When the polling stops, the DC level is held high and each responding device answers per its unique address by switching a resistor onto the DC circuit causing data to be readable at the panel. The steady DC level provides power for the MAPNET II communications receiver circuit and, for some low power devices, such as basic smoke/heat sensors and IAMs, can power the entire device – meaning only a single wire pair is required.

IDNet Communications*

What does it mean?

IDNet is an acronym for **I**ndividual **D**evice **N**etwork. The IDNet design is the next generation of addressable device communications, improving upon the basic MAPNET II communications protocol.

Where is it used?

IDNet communications are provided by the Simplex® 4010, 4010ES, 4100U, 4100ES, and 4008 Fire Alarm Control Panels. In addition to MAPNET II/IDNet addressable devices, IDNet communications also control unique devices such as the IDNet Isolator base, the 4009 IDNet NAC Extender, and the Security IAM. 4010ES, 4100ES and later versions of 4100U software (revision 11 and higher) also communicate with multi-point relays and the multi-sensor. However, different panels may provide slightly different IDNet device compatibility.

What does it do?

The operation is similar to MAPNET II but there are significant differences. The IDNet protocol and hardware enhancements support up to **250 addressable devices** on a single wire pair and can support additional device types and different operations. (The 4008 Fire Alarm Control Panel provides up to 200 addressable device support.)

How does it work?

Basic operation is similar to that of MAPNET II but with an expanded capability that requires a different control panel to decode the additional device types and operations available with IDNet communications.

What is the difference between 4010 IDNet and 4010ES/4100U/4100ES IDNet?

The basic communications protocol of IDNet is similar, just as RS-232 or RS-485 is similar. However, even though the IDNet communications protocol is similar, not all control panels can recognize all addressable devices. For compatibility reasons, there is a distinction between 4008 and 4010 and 4010ES/4100U/4100ES IDNet.

What is the difference between 4010 IDNet and 4008 IDNet?

The 4008 Addressable panel provides a unique set of features. It is for smaller applications and only two photoelectric sensitivity levels are supported. However, it is capable of controlling the 4090-9116 IDNet Communications Isolator, and it is compatible with the 4090-9007 IDNet Signal IAM.

What is IDNet+?

IDNet+ is a 4010ES/4100U/4100ES device communications circuit that provides isolated IDNet communications for improved noise immunity. This allows IDNet circuits to use existing unshielded and untwisted wiring in conduit with other fire alarm circuits. It includes a built-in quad isolator (or dual isolator for 4010ES base panels) for superior survivability and is compatible with IDNet devices supported by 4010ES/4100U/4100ES IDNet.

TYCO, SIMPLEX, and the product names listed in this material are marks and/or registered marks. Unauthorized use is strictly prohibited. Please note that listings and approvals shown on page 1 that are under Simplex Time Recorder Co. are the property of Tyco Fire Protection Products.



Tyco Fire Protection Products • Westminster, MA • 01441-0001 • USA

S4090-0011-14 5/2013

www.simplexgrinnell.com

© 2013 Tyco Fire Protection Products. All rights reserved. All specifications and other information shown were current as of document revision date and are subject to change without notice